

# MONITORED PORTABLE ALARMS



## Introduction

The Monitored Portable Alarm is designed specifically for use on construction sites, site huts and/or incomplete buildings etc.

This is an area that has proven to be easily targeted by the criminal fraternity, with appliances, fittings, copper piping and cabling, units and tools being stolen with ease.

Not only is there the loss of valuable items, but the down time in dealing with such matters that can be very costly as well.

Insurance company claims have escalated to extreme levels, boosting up premiums and excess payments.

Until now there has been limited options to secure these sites and situations.

This totally portable alarm unit has the advantage of being **monitored 24 hours a day by CODE 9**. Meaning that if an intrusion is detected by the alarm; immediate follow up action can be commenced. This can be simply a phone call to a nominated party, a patrol despatch, or both.

This totally portable alarm unit merely requires to be plugged into a 230v power supply. An internal battery if fully charged, will keep the alarm active for up to 20 to 80 hours (depending on model) if the power is accidentally or purposely disconnected.

CODE 9 continually monitors the alarm over a dedicated security radio network. This means that if an intrusion is detected, the monitoring centre can implement immediate follow up action. This can be a call to your nominated contact person, a call to the patrol response company, or both.



# MONITORED PORTABLE ALARMS



## Features

- Monitored 24 hours a day by CODE 9
- Reports
  - Mains power on or off
  - Alarm armed or disarmed
  - Activation signal
  - Tamper signal
  - Low battery signal
- Backup battery
- One remote pendant for arming and disarming
- Piezo siren
- PIR movement detector mounted on front panel
- Keypad mounted on front panel
- Built in radio transmitter, that reports to the monitoring centre in 1 second
- Extra detection devices and pendants available
- Carry handle
- Non scratch pads on base

## Attributes

- Mains powered
- Battery backup of approximately 80 hours for 1728 & SP models, if mains power is disconnected.
- Battery backup of approximately 25 hours for 1759 & MG models, if mains power is disconnected.
- Alarm unit will report status update every 12 hours.
- Alarm unit will report mains power failure if power is off for more than 15 minutes.
- Alarm unit will report, if unit is tampered with.
- Alarm unit will report set (armed) or unset (disarmed) condition.
- Alarm unit will report activation's instantly.
- Unit must be plugged in to mains power when not used, or stored. It is best to advise the CODE 9 monitoring centre of periods when signals are to be ignored.

**Alarm Solutions can be contacted on (03) 377 7575**

# MONITORED PORTABLE ALARMS



## Pricing Structure

The standard monitored portable alarm unit is valued at **\$1350.00 + GST**

A Standard Portable Monitored Alarm may be leased for a minimum period of two months at a rate of:

\$120.00 + GST per month with Critical level 1 monitoring  
\$130.00 + GST per month with Business level 2 monitoring.

**Plus** Delivery, installation and demonstration costs, if applicable. (\$55/hr plus Travel)

Extras available	Lease per month
Standard hard wired PIR	\$10
Pet Proof hard wired PIR	\$15
Standard hard wired Smoke detector	\$15
Remote Pendant	\$15
Wireless RF PIR detector	\$30 (MG Panel only)
Wireless RF Universal Door Reed switch	\$30 (MG Panel only)
Wireless RF Smoke detector	\$40 (MG Panel only)

All pricing excludes GST

## Monitoring

### Critical Level 1 Monitoring

This is the standard monitoring service and will detect arm/disarm, activation and mains power loss. The monitoring centre, upon activation or mains power loss, will contact the client or send a patrol, or both (whatever is requested in the contract). Excessive calls to cell phones will incur additional charges to recover costs.

### Business Level 2 Monitoring

This is the same service as Critical Level Monitoring, plus the additional feature of failure to arm the system. If the system is not armed by an agreed time each evening, the monitoring centre will contact the client. Excessive calls to cell phones will incur additional charges to recover costs.

### Patrols

CODE 9's patrol companies of choice are Triton Security & Sub 5 Security, but other companies can be used if preferred. The patrol will survey the exterior of the property or premises to detect forced entry, or any damage; or enter premises if keys and codes are available.

- \$48.00 + GST approx. per call out. Within the Christchurch area

# MONITORED PORTABLE ALARMS

## User Instructions

### Paradox Models



#### Installing Unit:

- Place main unit on bench or floor, preferably in a corner, which gives best coverage, but will also deny unauthorised access to the unit.
- Plug unit into mains power. (Orange AC LED will glow)
- Place second PIR sensor if applicable, facing the item or area to be protected.
  - If mounted on floor, place sensor upside down.
  - If mounted on a bench, cupboard or wall, place sensor normal way up.
- Walk test sensors to test effectiveness of coverage.

#### Turning On (Arming) Unit:

- Turn unit on with pendant remote, or press and hold the FORCE or ARM button on keypad.

NB: When arming with pendant, you must be outside the protected area.  
When arming with keypad you must vacate the protected area within 10 seconds.

- Siren will squawk once.
- 'Arm' LED will glow.

#### Turning Off (Disarming) Unit:

- When re-entering premises, turn unit off with pendant remote, or with the correct four (4) digit code in keypad.
  - Siren will squawk twice.
  - 'Arm' LED will go out.

NB: Unit **MUST** be turned off before detecting your presence.  
(There is no entry delay, so alarm will activate if using keypad)

Please identify your unit by its' five (5) digit account number when talking with CODE 9

CODE 9 can be contacted on (03) 374 3424

---

## Remote Pendant Information

ON and OFF Button



ON Button



OFF Button

#### **Remember!**

When unit turns **on** the siren will **squawk once**.  
When unit turns **off** the siren will **squawk twice**.

# Keypad Information

## 1728 & 1759 Models

### READY LED

ON = zones closed  
 OFF = zones open  
 FLASHING = exit delay

### ARMED LED


ON = Alarm armed  
 OFF = Alarm disarmed  
 FLASHING = Alarm activated

### AC LED

ON = power present  
 OFF = power failure

### ZONE DISPLAY

When these buttons are illuminated, the corresponding zone is open



Use these buttons to enter 4 digit code to disarm system

Press and hold FORCE button to arm system

## SP & MG Models

### ARMED LED

ON = Alarm armed  
 OFF = Alarm disarmed  
 FLASHING = Alarm activated

### AC LED

ON = power present  
 OFF = power failure

### ZONE DISPLAY

When these buttons are illuminated, the corresponding zone is open



Use these buttons to enter 4 digit code to disarm system

Press and hold ARM button To arm system